


# 5. Part Name



Name	Quantity	Name	Quantity
a Tail	1	j Hexagonal Nut (for Hub use)	1
b Body	1	k Nose Cone	1
c Screw Plug	1	l Hub 1	1
d Tail Shaft	1	m Hub 2	1
e Long Nut (for Yaw Shaft use)	4	n Blades	3
f Yaw Shaft Cover	1	o Instruction Manual (this document)	1
g Insulator	1	p Wrench (13mm / 17mm)	1
h Cap Bolt (for Yaw Shaft use)	4	q Hexagonal Wrench (8mm / 6mm)	1
i C Ring	1	r E-ring (1pc. for spare)	2